


- cs** Montážní list
- da** Installationsvejledning
- de** Installationsanleitung
- el** Οδηγίες Εγκατάστασης
- en** Installation Instructions
- es** Instrucciones de montaje


- fi** Asennusohje
- fr** Instructions d'installation
- hu** Telepítési leírás
- it** Istruzioni di montaggio
- nl** Installatie-aanwijzing
- pl** Instrukcja montażu



- pt** Instruções de montagem
- sk** Návod na montáž
- sv** Installationsanvisning
- tr** Montaj talimatları
- zh** 安装说明书

RAB...




RAB11, RAB11.1, RAB21, RAB21.1, RAB31, RAB31.1






Dimensions in mm




RAB11, RAB11.1

- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat
- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V
- Y Control output "Valve actuator", AC 24...250 V
- D Zone valve or thermal valve



RAB21, RAB21.1
Heating or Cooling


- D1 Zone valve or thermal valve for heating or cooling
- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat



RAB21, RAB21.1


Changeover for heating or cooling with external aquastat

- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V
- Y1 Control output "Valve actuator heating", AC 24...250 V
- Y2 Control output "Valve actuator cooling", AC 24...250 V
- S1 Aquastat e.g. Z182 / RYT182



RAB31, RAB31.1

- D1 Zone valve or thermal valve for heating
- D2 Zone valve or thermal valve for cooling
- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat
- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V
- Y1 Control output "Valve actuator heating", AC 24...250 V
- Y2 Control output "Valve actuator cooling", AC 24...250 V



RAB91

- L Switching voltage AC 24...250 V
- M1 3-speed fan
- N Neutral
- N1 Room thermostat
- Q1 Control output "Fan speed I", AC 24...250 V
- Q2 Control output "Fan speed II", AC 24...250 V
- Q3 Control output "Fan speed III", AC 24...250 V